




# BR SOFT RELEASE RUNNING TOOL

## ASSEMBLY DESCRIPTION

The B & T BR Soft Release Running Tool sets bottom hole gauges, or other pressure instruments.





## BR SOFT RELEASE RUNNING TOOL

SPECIFICATIONS	
	1.500
Fishneck	1.188
Connections	15/16"-10

All Specification Tables contain approximated dimensions and should be used for reference only.