



MEASURING HEAD ASSEMBLY

ASSEMBLY DESCRIPTION

The Measuring Head Assembly is used to measure wire sizes ranging from 0.092" to 0.125", and can be adapted for cable drive or direct drive.

B & T manufactures the 8" and 16" assemblies, as well as all of the replacement parts for any size Measuring Head Assembly.

