



RELEASING TOOL

ASSEMBLY DESCRIPTION

The Releasing Tool is used to release the fishneck from the skirt on the B & T R Pulling Tool and the B & T S Pulling Tool.

